



## Updating the Firmware for the DS-9000/2600

**SUBJECT:** Update firmware on the DS-9000/2600.

**OBJECTIVE:** Provide the directions to update the DS-9000/2600.

**REQUIRED ITEMS:** Windows PC, DS-9000/2600, KP-30 micro USB cable, DS9000\_DS2600\_FWUPDATE\_Vxxx.exe file, and "CR-21" (optional)


**NOTE:** In order to update the firmware, the battery power level **MUST** be greater than 50%. The recorder will not update if battery level is lower than 50%.

### **Download software**


Download the provided firmware updater and save to the computer used to update the DS-9000/2600.

### **Procedure**


1. Start the DS-9000/2600 Firmware Updater by double left clicking the DS9000\_DS2600\_FWUPDATE\_Vxxx.exe.




2. Turn on the DS-9000/2600 then connect it to the PC.



3. Click "Start".



4. Update screen will display. While transferring the update, the LCD screen on the DS-9000/2600 should say busy.





5. Complete. Click "Finish" then disconnect the DS-9000/2600 from PC. After disconnecting the recorder, allow it to go through the updating process before turning it off. ("See the recorder's LCD screen").

